

LH – Laser Head

X7 X6 X5 X4

E – Laser Control

X6 X5 X4 X3

PS – Power supplies

PS3

PS1

PS2

